



PhotoBook maker

FASTBIND FOTOMOUNT M3 ™



Deluxe PhotoBooks

Fastbind FotoMount M3 is a deluxe PhotoBook maker using the pioneering Fastbind Mountinglift™ system (patents pending). With the exceptionally precise Mountinglift, you make professional deluxe PhotoBooks faster and easier than ever before. Tabletop in size, it offers the flexibility and quality previously available only from equipment costing much more. Using photographic paper, card, laminated material or any print for your pictures, you can produce any book format from 50 x 50 mm up to 305 x 305 mm (12 x 12") and you achieve an edge-to-edge panoramic view on each page. The book cover can be either a standard cover or a digitally printed custom made cover*. In a matter of minutes you can create a beautiful, professional PhotoBook yourself, saving time and adding more profit to your bottom line.



Fastbind FotoMount M3 is a superior solution, designed specifically with the photographic studio, photo lab and professional photographer in mind. It also perfectly meets the needs of digital printers, copy shops and on-demand publishers who can offer premium PhotoBooks to their customers.

Easy to use and economical

The Fastbind FotoMount™ product line provides all the supplies needed to mount a PhotoBook. With only two types of supplies you can manage all album sizes (up to 305 x 305 mm and 80 mm thick): Fastbind PhotoBook mounting sheets™ form the core of the book block and Fastbind PhotoBook end sheets™ attach your book block to the cover.

Specifications (2007/11)

	Metric	Inches
Max print size	305 x 610 mm	12 x 24"
Min album size	50 x 50 mm	2 x 2"
Max album size	305 x 305 mm	12 x 12"
Max binding thickness	80 mm	3"
Machine dimensions	514 x 610 x 320 mm	20.2 x 24 x 12.6"
Package dimensions	586 x 700 x 406 mm	23.1 x 27.6 x 16"
Net / gross weight	18/19.5 kg	40 / 43 lbs

Manual operation (no electricity required).

Cover guide with two cover positioning holders included.

Fastbind Mountinglift system: patents pending.



Fastbind FotoMount M3 is a compact, tabletop unit.



A cover guide and two cover positioning holders are included.



The finished book opens astonishing 180 degrees.

The revolutionary Mountinglift™

- 1. After printing, crease the pictures in the center. **
- 2. Bind the creased pictures into a block with Fastbind mounting supplies. Secure the block through the binding process with two magnet clamps, and use the Mountinglift for smooth and accurate positioning. Use a cutter/guillotine to trim the block. ***
- 3. Place the cover guide on FotoMount M3 and use the cover positioning holders to secure the cover on its place. Mount the trimmed block to the cover by removing the silicon papers from the end sheets. Your deluxe PhotoBook is ready!

CE

- For top quality personalized hard covers, we recommend Fastbind case makers (not included)
- For optimized creasing, we recommend Fastbind creasers (not included)

Product information as of 2007/11 and is subject to change without notice.

